


Spark Plug (Refer to the maintenance precautions on page 48).

Recommended plugs:

Standard: C6HSA (NGK)

1. Disconnect the spark plug cap (1) from the spark plug.
2. Clean any dirt from around the spark plug bases. Remove the spark plug using the plug wrench furnished in the tool kit.
3. Inspect the electrodes and center porcelain for deposits, erosion or carbon fouling. If the erosion or deposit is heavy, replace the plug. Clean a carbon or wetfouled plug with a plug cleaner, otherwise use a wire brush,



(1) Spark Plug Cap