

(Ref. No.) Description	Function
(6) Turn signal indicator (green)	Flashes when either turn signal is operated.
(7) Neutral indicator (green)	Light when the transmission is in neutral.
(8) High beam indicator (blue)	Light when the headlight is on high beam.
(9) Tripmeter reset knob	Resets tripmeter to zero (0). Turn knob in direction shown.