

Loading

The combined weight of the rider, passenger, luggage and additional accessories must not exceed 196 kg (432 lbs), the vehicle capacity load. Luggage weight alone should not exceed 22 kg (49 lbs).

1. Keep luggage and accessory weight low and close to the center of the motorcycle. Load weight equally on both sides to minimize imbalance. As weight is located farther from the motorcycle's center of gravity, handling is proportionally affected.
2. Adjust tire pressure (TIRES, page 24) and rear shock absorber springs (SUSPENSION, page 36) to suit load weight and riding conditions.

Carga

La carga combinada del conductor, pasajero, equipaje y accesorios adicionales no debe exceder de 196 kg. El peso del equipaje no deberá exceder de 22 kg.

1. Mantener el peso de la carga y de los accesorios bajo y cerca del centro de la motocicleta. El peso de carga por igual en ambos lados para reducir desequilibrios. A medida que el peso se coloca apartado del centro de gravedad de la motocicleta, la conducción queda proporcionalmente afectada.
2. Ajustar la presión de los neumáticos (NEUMATICOS, página 24) y los resortes del amortiguador trasero (SUSPENSION, página 36) de acuerdo con la carga y condiciones de conducción.