


## Anti Dive Damper Adjuster

This adjuster (1) can be adjusted to prevent nose-driving during braking. It is located at the side of the front fork and can be set to any one of four positions.

**CAUTION:** Make absolutely sure that the adjuster is set the same position at the left and right.

Position	Anti nose dive damper force
1	Soft
2	Medium
3	Hard
4	Extra hard



## Ajustador para evitar la caída hacia adelante durante el frenado

Este ajustador (1) puede ajustarse para evitar la caída hacia adelante durante el frenado. Está situado en la parte lateral de la horquilla delantera y puede colocarse en cualquiera de entre cuatro posiciones.

**PRECAUTION:** Asegurarse de manera absoluta que el ajustador se coloca en la misma posición a la izquierda y a la derecha.

Posición	Efecto para evitar la caída hacia adelante
1	Ligero
2	Estándar
3	Pesado
4	Máximo