

MAINTENANCE

page	
106	MAINTENANCE
106	THE IMPORTANCE OF MAINTENANCE
107	MAINTENANCE SAFETY
108	SAFETY PRECAUTIONS
109	MAINTENANCE SCHEDULE
112	TOOL KIT
113	SERIAL NUMBERS
114	COLOUR LABEL (Except BR type)
115	ENGINE OIL
122	CRANKCASE BREATHER
124	SPARK PLUGS
127	THROTTLE OPERATION
128	COOLANT
129	AIR CLEANER
130	DRIVE CHAIN
137	DRIVE CHAIN SLIDER
138	FRONT AND REAR SUSPENSION INSPECTION
139	SIDE STAND
140	WHEEL REMOVAL

page	
146	BRAKE PAD WEAR
148	BATTERY
151	FUSE REPLACEMENT
154	BRAKELIGHT SWITCH ADJUSTMENT
155	BULB REPLACEMENT
162	CLEANING
166	STORAGE GUIDE
166	STORAGE
168	REMOVAL FROM STORAGE
169	SPECIFICATIONS
173	CATALYTIC CONVERTERS