



Example

- If you set the subtraction trip mode and do not travel, you will have to re-enter the trip distance.
- If you set the subtraction trip mode and do not complete the set distance, the subtraction trip mode will reset to the initial setting.



Change to the set distance mode.



Reset to the initial setting.