

4. Reinstall the plug (4).
5. Install the oil filter element and tighten the filter cover (6), making sure the O-ring is in good condition.
6. Fill with approx. 2.3 liters (2.4 U.S. qt., 2.0 Imp. qt.) of recommended grade oil. Start the engine and run for several minutes; then stop it and recheck the oil level. Add oil if necessary.

**CAUTION: Change the oil more frequently than recommended on page 101, depending upon the severity of dust conditions.**

- 
4. Remonte los tapon (4).
  5. Instale el elemento del filtro de aceite y apriete la cubierta del filtro (6), asegurándose de que la junta anular esté en buen estado.
  6. Llene el cárter con 2,3 litros, aproximadamente, de aceite de la calidad recomendada. Arranque el motor y haga marchar por unos minutos; luego, párelo y revise el nivel de aceite otra vez. Agregue aceite, si es necesario.

**PRECAUCIONES: Cambie el aceite más frecuentemente que lo recomendado en la página 101, dependiendo de las condiciones de polvo en la zona de conducción.**