

Fuel Tank


Fuel tank capacity is 2.7 U.S. gal. (11ℓ) including 0.7 U.S. gal. (2.5ℓ) in the reserve supply. Press down on the cap ① and then push in the lock to open the fuel tank cap.

Use of 91 research octane low-lead gasoline or higher is recommended. If low-lead gasoline is not available, you may use a leaded regular grade gasoline.

When refueling take care to exclude dirt, water, or other contaminants from the fuel tank.

WARNING:

Gasoline is flammable and explosive under certain conditions. Always stop the engine and do not smoke or allow open flames or sparks near the motorcycle when refueling.



←① Fuel tank cap

Ⓐ Press down

Ⓑ Push in