


### Lubrication:

Normally drive chain lubrication is performed without removing the chain, at the time of chain adjustment.

More frequent inspection and servicing is required under severe operating conditions.



the chain for wear (sloppy joints), stiffness and binding at the joints, and broken or separated rollers. Apply a liberal amount of good engine oil or chain lubricant.

If damaged or worn, the chain should be replaced. Replacement of the endless chain requires a special tool, therefore your Honda dealer should be consulted.

- b. Adjust drive chain as described in steps "a-e", page 54.

- a. The CB360 and CB360G are equipped with the endless type drive chain and requires periodic inspection. If dirty or rusted, clean with brush and solvent, wipe and dry with a clean rag. Inspect