


# Storage Compartment

## Helmet Holder

The helmet holder is located on the left side below the seat.



- ▶ Use the helmet holder only when parked.
- ▶ There is also another helmet holder located on under the seat. ➔ P.26

## Using the Helmet Holder

- 1 Insert the ignition key and turn it clockwise to unlock.
- 2 Hang your helmet on the holder hook.
- 3 Turn the key counterclockwise to lock the holder hook and then remove the key.

## ⚠ WARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.