
Centre Compartment


The centre compartment is located under the seat. Maximum Weight Limit: **3.0 kg (6.6 lb)**

(CB400) Centre compartment



Centre compartment





► The centre compartment may become heated by the engine. Do not store any items that are flammable or susceptible to heat damage.

Removing the Seat P.45

27