

## Removing & Installing Body Components ▶ Battery





- **3.** Disconnect the negative ⊖ terminal from the battery.
- **4.** Disconnect the positive ⊕ terminal from the battery.
- **5.** Remove the battery taking care not to drop the terminal nuts.

## **I** Installation

Install the parts in the reverse order of removal. Always connect the positive  $\oplus$  terminal first. Make sure that bolts and nuts are tight.

The clock will be reset AM 1:00 if the battery is disconnected.
To set the clock, see "Operation Guide." ▶P.17

For proper handling of the battery, see "Maintenance Fundamentals." ▶P.36
Battery Goes Dead ▶P.86

48