

## **MAINTENANCE**

<b>page</b>		<b>page</b>	
67	<b>MAINTENANCE</b>	111	Stoplight Switch Adjustment
67	The Importance of Maintenance	112	Bulb Replacement
68	Maintenance Safety		
69	Safety Precautions	118	<b>CLEANING</b>
70	Maintenance Schedule		
73	Tool Kit	122	<b>STORAGE GUIDE</b>
74	Serial Numbers	122	Storage
75	Colour Label	124	Removal from Storage
76	Engine Oil		
80	Crankcase Breather	125	<b>SPECIFICATIONS</b>
81	Spark Plugs		
84	Throttle Operation	129	<b>CATALYTIC CONVERTER</b>
85	Idle Speed		
86	Air Cleaner	130	<b>NOISE CONTROL SYSTEM (AUSTRALIA ONLY)</b>
87	Coolant		
88	Drive Chain		
94	Drive Chain Slider		
95	Front and Rear Suspension Inspection		
96	Side Stand		
97	Wheel Removal		
104	Brake Pad Wear		
106	Battery		
108	Fuse Replacement		