

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Neutral indicator
- (3) High beam indicator
- (4) Low oil pressure indicator
- (5) Fuel indicator
- (6) Tachometer
- (7) Tachometer red zone
- (8) Coolant temperature gauge
- (9) Right turn signal indicator
- (10) Right control button
- (11) Immobilizer system (HISS) indicator
- (12) PGM-FI malfunction indicator lamp (MIL)
- (13) Left control button
- (14) Left turn signal indicator
- (15) Odometer/Tripmeter/Digital clock display

