

5. Tyres—check condition and pressure (pages 38 – 43 ).
6. Drive chain—check condition and slack (page 97 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions.
8. Lights and horn—check that headlight, stop/tail light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 50 ).
10. Side stand ignition cut-off system—check for proper function (page 105 ).