

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
	DRIVE CHAIN		I, L EVERY 1,000 km (600 mi)								97
	DRIVE CHAIN SLIDER				I		I		I	103	
	BRAKE FLUID	NOTE (4)		I	I	R	I	I	R	27	
	BRAKE PAD WEAR			I	I	I	I	I	I	111	
	BRAKE SYSTEM		I		I		I		I	27, 111	
*	BRAKE LIGHT SWITCH				I		I		I	—	
*	HEADLIGHT AIM				I		I		I	—	
	CLUTCH SYSTEM		I	I	I	I	I	I	I	30	
	SIDE STAND				I		I		I	105	
*	SUSPENSION				I		I		I	104	
*	NUTS, BOLTS, FASTENERS		I		I		I		I	—	
**	WHEELS/TYRES				I		I		I	—	
**	STEERING HEAD BEARINGS		I		I		I		I	—	