


Crankcase Breather

1. Remove the drain plug (1) from the tube, and drain the deposits.
2. Reinstall the drain plug.

NOTE :

- Service more frequently when ridden in rain, at full throttle or after the motorcycle is washed or overturned.
- Service if the deposit level can be seen in the transparent section of the drain tubes.



Reniflard de carter moteur

1. Déposer le bouchon de vidange (1) du tuyau et vidanger les dépôts.
2. Remettre le bouchon de vidange.

NOTE :

- Faire réviser plus souvent si l'on conduit la motocyclette sous la pluie à pleins gaz ou après l'avoir lavée ou retournée.
- Faire réviser si le niveau du dépôt est visible dans la section transparente des tubes de vidange.