

5. To set the minute, press the RESET button until the desired minute appears.
  - Quick setting – press and hold the RESET button until the desired minute appears.
6. To end the adjustment, press the SEL button (E type) or press and hold the SEL button and RESET button for more than 2 seconds (except E type).

The display will stop flashing automatically and the adjustment will be cancelled if the button is not pressed for about 30 seconds.

As you turn off the ignition switch during the presetting procedures, the preset data just before turning off the ignition switch will be registered.

The clock will be reset 1:00 if the battery is disconnected.