

MAINTENANCE

page

98 MAINTENANCE

- 98 THE IMPORTANCE OF MAINTENANCE
- 99 MAINTENANCE SAFETY
- 100 SAFETY PRECAUTIONS
- 101 MAINTENANCE SCHEDULE
- 104 TOOL KIT
- 105 SERIAL NUMBERS
- 106 COLOUR LABEL
< Except BR type >
- 107 ENGINE OIL
- 113 THROTTLE OPERATION
- 114 COOLANT
- 115 DRIVE CHAIN
- 121 DRIVE CHAIN SLIDER
- 122 FRONT AND REAR SUSPENSION INSPECTION
- 123 SIDE STAND
- 124 WHEEL REMOVAL
- 132 BRAKE PAD WEAR
- 134 BATTERY

page

- 136 FUSE REPLACEMENT
- 140 BRAKELIGHT SWITCH ADJUSTMENT
- 141 BULB REPLACEMENT
- 149 CLEANING**
- 154 STORAGE GUIDE**
- 154 STORAGE
- 156 REMOVAL FROM STORAGE
- 157 TAKING CARE OF THE UNEXPECTED**
- 158 SPECIFICATIONS**
- 162 CATALYTIC CONVERTER**