



## Front Turn Signal Bulb

The right and left turn signal bulbs replacement can be done in the same way.

1. Remove the screw (1).
2. Fold the rearview mirror (2).

3. Remove the cover (3) from the rearview mirror carefully in the procedure shown in the illustration.



(1) Screw

(2) Rearview mirror

(3) Cover