


## Digital Clock


Shows hour and minute. To set the digital clock, proceed as follows:

1. Turn the ignition switch ON.
2. Push and hold both the MODE button (2) and RESET button (3) for more than 2 seconds. The clock will be set in the adjust mode with the hour display flashing.



- (1) Digital clock
- (2) MODE button
- (3) RESET button

3. To set the hour, push the RESET button until the desired hour and AM/PM are displayed.
  - The time is advanced by one hour, each time the button is pushed.
  - The time advances fast when the button is pushed and held.



4. Push the MODE button. The minute display will start flashing.

