

(Ref.No.) Description	Function
(13) High beam indicator (blue)	Lights when the headlight is on high beam. Should also lights for a few seconds and then go off when the ignition switch is turned ON.
(14) Right turn signal indicator (green)	Flashes when the right turn signal operates. Should lights for a few seconds and then go off when the ignition switch is turned ON.