



4. Press the select button. The minute display will start flashing.



5. To set the minute, press the reset button until the desired minute. The minute display will return to "00" when "60" is reached without affecting the hour display.

6. To end the adjustment, press the select button or turn the ignition switch OFF. The display will stop flashing automatically and the adjustment will be cancelled if the button is not pressed for about 30 seconds.