


### Initial Display

When the ignition switch is turned ON, the multi-function display (1) and fuel gauge (2) will temporarily show all the modes and digital segments. Thereafter, the speedometer (3) will show from 290 km/h to 0 km/h (E, IIIE type: From 180 mph to 0 mph in mph) so that you can make sure the liquid crystal display is functioning properly.

The unit "mph" (4) and "mile" (5) will be displayed for E, IIIE type.

Digital clock (6) and tripmeter (7) will reset if the battery is disconnected.



- (1) Multi-function display
- (2) Fuel gauge
- (3) Speedometer
- (4) "mph"
- (5) "mile"
- (6) Digital clock
- (7) Tripmeter