

5. Tyres—check condition and pressure (pages 46 – 51 ).
6. Drive chain—check condition and slack (pages 106 – 107 ). Adjust and lubricate if necessary.
7. Throttle—check for smooth opening and full closing in all steering positions (page 104 ).
8. Lights and horn—check that headlight, brake/taillights, position light, license light, turn signals, indicators and horn function properly.
9. Engine stop switch—check for proper function (page 58 ).
10. Side stand ignition cut-off system—check for proper function (page 114 ).