

# MAINTENANCE

page

## **89 MAINTENANCE**

- 89 THE IMPORTANCE OF MAINTENANCE
- 90 MAINTENANCE SAFETY
- 91 SAFETY PRECAUTIONS
- 92 MAINTENANCE SCHEDULE
- 95 TOOL KIT
- 96 SERIAL NUMBERS
- 97 COLOUR LABEL  
< Except BR, IIBR type >
- 98 ENGINE OIL
- 104 SPARK PLUGS
- 110 THROTTLE OPERATION
- 111 COOLANT
- 112 DRIVE CHAIN
- 118 DRIVE CHAIN SLIDER
- 119 FRONT AND REAR SUSPENSION INSPECTION
- 120 SIDE STAND
- 121 WHEEL REMOVAL
- 128 BRAKE PAD WEAR
- 130 BATTERY
- 132 FUSE REPLACEMENT

page

- 135 BRAKELIGHT SWITCH ADJUSTMENT
- 136 BULB REPLACEMENT

## **142 CLEANING**

## **147 STORAGE GUIDE**

- 147 STORAGE
- 149 REMOVAL FROM STORAGE

## **150 TAKING CARE OF THE UNEXPECTED**

## **151 SPECIFICATIONS**

## **156 CATALYTIC CONVERTER**