


## Speed and Mileage Unit Change

**< E, III E type only >**

The speedometer displays both "km/h" and "mph".

The odometer/tripmeter displays both "km" and "mile".

Push the RESET button (6) to select "km/h"/"km" or "mph"/"mile" with the display in the tripmeter A mode.



(6) RESET button