


HEADLIGHT AIM VERTICAL ADJUSTMENT

Vertical adjustment can be made by turning the adjuster (1) in or out as necessary. Obey local laws and regulations.



(1) Adjuster

(A) Up

(B) Down