

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH								
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	101	
* AIR CLEANER		NOTE (2)				I			I	91	
SPARK PLUGS				EVERY 24,000 km (16,000 mi) I, EVERY 48,000 km (32,000 mi) R						96	
* VALVE CLEARANCE							I			—	
ENGINE OIL			R		R		R		R	92	
ENGINE OIL FILTER			R		R		R		R	93	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	102	
RADIATOR COOLANT		NOTE (3)			I		I		R	40	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	—	