

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to pages	
			x 1,000 km	1	6	12	18	24	30	36		
			x 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
	DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								76
	DRIVE CHAIN SLIDER					I			I		I	82
	BRAKE FLUID	NOTE (3)			I	I	R	I	I	R		19
	BRAKE PAD WEAR				I	I	I	I	I	I		92
	BRAKE SYSTEM			I		I		I		I		19, 92
*	BRAKE LIGHT SWITCH					I		I		I		—
*	HEADLIGHT AIM					I		I		I		—
	CLUTCH SYSTEM			I	I	I	I	I	I	I		23
	SIDE STAND					I		I		I		84
*	SUSPENSION					I		I		I		83
**	NUTS, BOLTS, FASTENERS			I		I		I		I		—
**	WHEELS/ TYRES					I		I		I		—
**	STEERING HEAD BEARINGS			I		I		I		I		—