


## Speed and Mileage Unit Change

### (E type only)

The speedometer displays both “km/h” and “mph”.

The odometer/tripmeter displays both “km” and “mile”.

Push the right control button (7) to select “km/h”/“km” and “mph”/“mile”.



(7) Right control button