


Battery Care

Inspecting and topping up the electrolyte level should be performed frequently as indicated in the Maintenance Schedule (page 101) and Pre-riding Inspection (page 88). The battery (1) is behind the right side cover. Remove the side cover. Check the electrolyte level.

The electrolyte level must be maintained between the upper (2) and lower (3) level marks on the side of the battery. If the electrolyte level is low, remove the battery filler caps (4).



Entretien de la batterie

La vérification du niveau d'électrolyte et son remplissage éventuel doivent s'effectuer à la fréquence indiquée dans le Programme d'entretien (page 103) et dans la section "Inspection avant conduite" (page 88). La batterie (1) se trouve derrière le cache latéral droit. Retirer le cache latéral. Vérifier le niveau d'électrolyte.

L'électrolyte doit se trouver entre les repères de niveau maximum (2) et minimum (3) situés sur le côté de la batterie. Si le niveau est bas, retirer les bouchons de remplissage (4) de la batterie.