

BRAKE SHOE WEAR

(Refer to the maintenance precautions on page 56). The rear brake is equipped with a brake wear indicator.


When the brake is applied, an arrow (1) attached to the brake arm (2) moves toward a reference mark (3) on the brake panel (4).

If the arrow aligns with the reference mark on full application of the brake, the brake shoes must be replaced.

NOTE:

* When the brake service is necessary, see your Honda dealer. Use only genuine Honda parts or its equivalent.

<REAR BRAKE>



(1) Arrow
(2) Brake arm

(3) Reference mark
(4) Brake panel