


# Parking

---

4. Use the helmet holder (2), located on the left side below the seat, to secure your helmet with your scooter:
- Open the seat (page 26).
  - Hang your helmet on the holder.
  - Lower the seat to lock.

To remove a helmet, open the seat (page 26). Remove the helmet from the helmet holder. Lower and push down on the seat until it locks. Make sure the seat is securely closed before riding.

## UNDER SEAT



(2) helmet holder