

If Your Engine Quits or Won't Start

| SYMPTOM: Engine starts, but runs poorly. | |
|---|--|
| POSSIBLE CAUSE | WHAT TO DO |
| idles roughly, too fast, stalls | Check engine idle adjustment (page 109). If the problem persists, see your Honda dealer. |
| overheating | Check the high coolant temperature indicator. Refer to <i>If Your Engine Overheats</i> , page 156. |
| runs erratically, misfires | May damage catalytic converter. See your Honda dealer. |
| blubbers (rich fuel mixture) | See your Honda dealer. |