## If You Have a Flat Tire

## Emergency Wheel Removal/Installation

Refer to Safety Precautions on page 70.

We recommend wheel removal be done only by your Honda dealer or another qualified mechanic. Do not attempt to remove the wheel on your own. Wheel removal requires mechanical skill and professional tools.