



Servicing Your Honda

Service Preparations

Maintenance Component Locations	52
Tools.....	55
Left Side Cover Removal	56
Left Fuel Tank Shroud Removal.....	57
Right Fuel Tank Shroud Removal.....	58
Clip Removal	59

Service Procedures

Fluids & Filters

Fuel.....	60
Engine Oil	63
Air Cleaner.....	69
Crankcase Breather	72

Engine

Throttle.....	73
Clutch System	76
Valve Clearance	78
Engine Idle Speed	81
Spark Plug	82
Spark Arrester	84

Chassis

Suspension	87
Brakes.....	90
Wheels.....	96
Tires & Tubes	101
Side Stand	105
Drive Chain.....	106

Electrical

Battery.....	113
Appearance Care.....	118

