


## STARTER BUTTON

The starter button (1) is next to the throttle grip.

When the starter button is pressed, the starter motor cranks the engine. See page 38 for the starting procedure.




(1) Starter button

## ENGINE STOP BUTTON

The engine stop button (1) is next to the left handlebar grip.

Push the button in and hold it in until the engine stops completely.



(1) Engine stop button