


DRIVE CHAIN SLIDER

Refer to the Safety Precautions on page 55 .

Check the chain slider (1) for wear. When the thickness of the chain slider reaches the limit, the chain slider must be replaced. See your Honda dealer.

Chain slider thickness limit:
3.5 mm (0.14 in)



(1) Chain slider