

Contents

MOTORCYCLE SAFETY..... 1		
Important Safety Information 2		
Important Safety Precautions 2		
Accessories & Modifications 3		
Accessories & Modifications 3		
Labels 4		
INSTRUMENTS & CONTROLS..... 9		
Operation Component Locations 10		
Indicator 11		
MIL Blink Pattern 11		
Current DTC/Freeze DTC 11		
Circuit Inspection 12		
DTC Index 13		
BEFORE RIDING..... 15		
Are You Ready to Ride? 16		
Is Your Motorcycle Ready to Ride? 17		
Pre-ride Inspection 17		
BASIC OPERATING INSTRUCTIONS 19		
Basic Operating Instructions 20		
Safe Riding Precautions 20		
Starting & Stopping the Engine 21		
Fast Idle Knob 21		
Preparation 21		
Starting Procedure 21		
How to Stop the Engine 22		
Break-in Guidelines 23		
SERVICING YOUR HONDA..... 25		
<i>Before You Service Your Honda</i>		
The Importance of Maintenance 26		
Maintenance Safety 27		
Important Safety Precautions 27		
Maintenance Schedule 28		
General Competition Maintenance 30		
Before & After Competition Maintenance 34		
Between Heats & Practice Maintenance 34		
After Competition Maintenance 34		
	<i>Service Preparations</i>	
	Maintenance Component Locations 36	
	Seat 37	
	Fuel Tank 38	
	Subframe 40	
	<i>Service Procedures</i>	
	<u>Fluids & Filters</u>	
	Fuel System 44	
	Fuel 44	
	Refueling Procedure 44	
	Fuel Line 44	
	Fuel Pressure Relieving 45	
	Fuel Line Replacement 45	
	Fuel Pump Filter Replacement 48	
	Fuel Pressure Increasing 52	
	Engine Oil 53	
	Oil Recommendation 53	
	Checking & Adding Oil 54	
	Changing Engine Oil & Filter 54	
	Transmission Oil 56	
	Oil Recommendation 56	
	Checking & Adding Oil 57	
	Replacing Transmission Oil 57	
	Coolant 58	
	Coolant Recommendation 58	
	Checking & Adding Coolant 58	
	Cooling System Inspection 59	
	Coolant Replacement 59	
	Air Cleaner 60	
	Cleaning 60	
	Crankcase Breather 62	
	Draining 62	
	<u>Engine</u>	
	Throttle 63	
	Throttle Freeplay 63	
	Throttle Inspection 64	
	Engine Idle Speed 65	
	Idle Speed Adjustment 65	
	Clutch System 66	
	Clutch Lever Adjustment 66	
	Clutch Lever Freeplay 66	
	Other Inspections & Lubrication 67	
	Clutch Operation 67	
	Clutch Disc/Plate Removal 68	
	Clutch Disc/Plate Inspection 69	
	Clutch Disc/Plate Installation 69	
	Spark Plug 71	
	Spark Plug Recommendation 71	
	Spark Plug Inspection & Replacement 71	
	Valve Clearance 72	
	Cylinder Head Cover Removal 72	
	Positioning At TDC On The Compression Stroke 72	
	Valve Clearance Inspection 73	
	Camshaft Removal 74	
	Shim Selection 76	
	Camshaft Installation 77	
	Crankshaft Hole Cap Installation 79	
	Cylinder Head Cover Installation 79	
	Piston/Piston Rings/Piston Pin 81	
	Cylinder Head Removal 81	
	Cylinder Removal 83	
	Piston Removal 84	
	Piston Ring Removal 84	
	Piston/Piston Pin/Piston Ring Inspection 84	
	Piston Ring Installation 85	
	Piston Installation 85	
	Cylinder Installation 86	
	Cylinder Head Installation 87	