

# Index

---

|                           |        |
|---------------------------|--------|
| shoe, brake .....         | 85     |
| side cover, removal ..... | 55     |
| side stand.....           | 21, 97 |
| spark arrester .....      | 77     |
| spark knock .....         | 56     |
| spark plug.....           | 75     |
| specifications .....      | 130    |
| stand, side.....          | 21, 97 |
| starting, engine .....    | 31     |
| stop button, engine ..... | 20     |
| stopping engine .....     | 33     |
| storage .....             | 115    |
| suspension,               |        |
| front.....                | 79     |
| rear.....                 | 80     |

## T

|                                 |        |
|---------------------------------|--------|
| throttle                        |        |
| freeplay .....                  | 68     |
| operation.....                  | 20     |
| tires,                          |        |
| air pressure .....              | 93     |
| flat .....                      | 122    |
| replacing.....                  | 96     |
| tools .....                     | 54     |
| towing.....                     | 35     |
| training, rider.....            | 3, 151 |
| transporting .....              | 112    |
| troubleshooting, starting ..... | 121    |

## U

|                           |     |
|---------------------------|-----|
| unexpected problems ..... | 119 |
|---------------------------|-----|