

## Installation

1. Set the projection of the seat to the tank guide to attach the seat.
2. Push the rear end of the seat down to locate the mounting holes on either side.
3. Insert and tighten the 2 x 12mm bolts.
4. Pull up on front of seat to ensure it is secure.
5. Refit side covers – insert front locating lug into frame bracket and lock rear mounting screw.

## Removal

1. Remove both side covers
2. Remove 2 x 12mm screws from seat mountings.

