

11. Fill with approx. 1.5 liters (1.6 U.S. qt., 1.3 Imp. qt.) of recommended grade oil. Start the engine and run for several minutes; then stop it and recheck the oil level. If necessary, add the specified oil up to the upper level mark. Do not overfill. Check for oil leaks.

CAUTION: Change oil more frequently than recommended on page 98, depending upon the severity of dust conditions.

11. Rellene el cárter con 1,5 litros, aproximadamente, del aceite de la calidad recomendada. Arranque el motor y haga marchar durante unos minutos; luego, párelo y revise el nivel de aceite otra vez.

Si fuese necesario, añadir el aceite especificado hasta la marca de nivel superior. No llenar excesivamente. Comprobar si existen pérdidas de aceite.

PRECAUCION: Cambie el aceite más frecuentemente que lo recomendado en la página 100, conforme a las condiciones de polvos de la zona de conducción.