

### Parking

- Park on a firm, level paved surface.
- If you must park on a slight incline or loose surface, park so that the motorcycle cannot move or fall over.
- Make sure that high-temperature parts cannot come into contact with flammable materials.
- Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.
- To reduce the likelihood of theft, always lock the handlebar and remove the key when leaving the motorcycle unattended. Use of an anti-theft device is also recommended.

### ■ Parking with the Side Stand or Centre Stand

1. Stop the engine.
2. **Using the side stand**  
Push the side stand down.  
Slowly lean the motorcycle to the left until its weight rests on the side stand.

#### **Using the centre stand**

- Let down the centre stand, stand on the left side of the motorcycle. Hold the left handle grip and the left grab rail. Press down on the tip of the stand with your right foot and, simultaneously, pull up and back.
3. Turn the handlebar fully to the left.
    - ▶ Turning the handlebar to the right reduces stability and may cause the motorcycle to fall.
  4. Turn the ignition switch to the LOCK position and remove the key. ➡ P. 41