

## Current fuel mileage

The current fuel mileage shows the current or instant fuel mileage you are getting.

Display range: 0.0 to 99.9 km/l (l/100km, mile/l or mile/gal)

- When your speed is less than 7 km/h (5 mph): "--.-" is displayed
- Above 99.9 km/l (mile/l or mile/gal): "99.9" is displayed
- Above 99.9 l/100km: "--.-" is displayed

When "--.-" is displayed except for the above-mentioned cases, go to your dealer for service.



## Average fuel mileage

The average fuel mileage will be based on tripmeter A. Average fuel mileage since tripmeter A was reset.

Display range: 0.0 to 99.9 km/l (l/100km, mile/l or mile/gal)

- Above 99.9 km/l (mile/l or mile/gal): "99.9" is displayed
- Above 99.9 l/100km: "--.-" is displayed
- When the tripmeter A is reset: "--.-" is displayed

When "--.-" is displayed except for the above-mentioned cases, go to your dealer for service.



► **To reset the average fuel mileage:** P.27