


Clock setting

- 1 Select "CLOCK" menu on the main menu screen, and then the display moves to the menu screen of "CLOCK".  P. 28
- 2 Press the **SELECT** button until the desired hour is displayed.
 - ▶ Press and hold to move the hour fast.
- 3 Press the **SET** button. The cursor moves to the minute digits.



- 4 Press the **SELECT** button until the desired minute is displayed.
 - ▶ Press and hold to move the minute fast.
- 5 Press the **SET** button. The clock is set, and then the display returns to the main menu screen.