


Storage Equipment

Helmet holder

The helmet holder is located under the seat. A helmet set wire is in the tool kit. ➡ P. 67



▶ Use the helmet holder only when parked.

Removing the Seat ➡ P. 86

⚠ WARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.