

Symptom	Cause/remedy
Unable to connect <i>Bluetooth</i> ® device	Depending on the <i>Bluetooth</i> ® device and application software you use, it may take some time for the audio system to connect to device and to start playing an audio file.
	The connection may be temporarily disconnected when starting the engine, which is normal and not a malfunction. The <i>Bluetooth</i> ® device will be reconnected after the engine is started.
	Connection processing is performed only when it is in the audio modes which is for <i>Bluetooth</i> ® devices. Check the audio mode being selected. ➡ P. 50
	Change the audio mode (➡ P. 50) or turn off the power to the audio system and then turn it on again. The audio system will retry connecting to the <i>Bluetooth</i> ® device.
	Check that your <i>Bluetooth</i> ® device has been paired.
	Referring to the instruction manual of your <i>Bluetooth</i> ® device, check that your <i>Bluetooth</i> ® device is in connectable state.