


(P) Parking brake indicator

CTX700D only

Lights as a reminder that you have not released the parking brake lever.



← Left turn signal indicator

HISS indicator → P.117

- Comes on briefly when the ignition switch is turned on with the engine stop switch in the (Run) position. Goes off if the ignition key has the correct coding.
- Flashes every 2 seconds for 24 hours when the ignition switch is turned off.

→ Right turn signal indicator

High beam indicator

N Neutral indicator

Comes on when the transmission is in Neutral.