

## Changing Clutch Oil Filter

**CTX700D only**

Use a new Honda Genuine clutch oil filter or equivalent specified for your model.

### NOTICE

Using the wrong clutch oil filter can result in serious damage to the transmission.

1. Follow the steps 1-6 of Changing Engine Oil & Filter. ➤ P. 72
2. Remove the right under cowl. ➤ P. 67

3. Remove the clutch oil filter cover, clutch oil filter and spring by removing the clutch oil filter cover bolts.
  - Discard the oil and clutch oil filter at an approved recycling centre.

